

L-English C

R-English C

STOP – S-5

①	②	③	④	⑤	⑥	⑦	⑧	⑨	⑩	⑪	⑫	⑬	⑭	⑮	—	Æ	æ	æ	CE	Æ	CE
08	01	CB	*	P	£	£	[	]	(	)	Æ	Q	W	E	R	T	Y	U	I	O	P
CB	NI	CB	L15	Æ	CE	æ	Z	—	—	—	CE	A	S	D	F	G	H	J	K	L	œ
◆	◆	;	z	◆	‘	R	!	’	?	!	%	Z	X	C	V	B	N	M		?	y
—	Q	W	E	R	T	Y	U	I	O	P		Q	W	E	R	T	Y	U	I	O	P
A	fl	S	D	F	G	H	J	K	L	&	fl	A	S	D	F	G	H	J	K	L	&
ff	Z	X	C	V	B	N	M	-	:	;	ff	Z	X	C	V	B	N	M	-	:	;
\$	1	2	3	4	5	6	7	8	9	0	*	x	p	v	v	R		B	Z		
fi	q	w	e	r	t	y	u	i	o	p	fi	q	w	e	r	t	y	u	i	o	p
ffi	a	s	d	f	g	h	j	k	l	q	ffi	a	s	d	f	g	h	j	k	l	D9
ffi	z	x	c	v	b	n	m	,	.	ES	ffi	z	x	c	v	b	n	m	,	.	◆
◆	◆										◆	◆									

ROW	A	B	C	D	E	F	G	H	I	J	K	L	M	N	O	UNITS
1			l	i	‘	’	.	,		l	i	j	j		◆	5
2	s	f	t	)	(	]	[	t	f	i	j	CB	CB		◆	6
3	c	r	!	e	:	;	!	?	r	s	?	-	:	;	s	7
4	CB	q	a	b	g	o	I	I	z	c	e	Z	F	E	J	8
5	y	v	z		v	p			.	9	7	5	3	1	0	9
6	C	u	n	B	R	V	X	*	-		8	6	4	2	◆	9
7	x	k	y	d	h	a	x	J	g	o	k	P	A	L	T	9
8	K	fi							p	u	n	Q		O	◆	10
9	D		fl		fl	fi	q		b	h	d		Y	G	U	10
10	H			S	P		ff				ff			œ	N	11
11	P	L	B	F	w	æ	æ	S	E	F	£		E	æ	Z	12
12	R	&	Y	V	C	C	Z	m	L	A	w	M	T	R	B	13
13	D	A	Q	ffi	ffi	Æ	CE	O	O	G	Q	X	T	w	V	14
14	K	N	H	ffi	ffi	G	D	N	Y	H	m	K	U	X	U	15
15	&	Æ	CE	Æ	CE	W	M		..	M	W			—	◆	18

Veronese 59E

6 point– 6¾ Set
 7/8 point– 7½ Set
 8 point– 8¼ Set
 9/10 point– 9 Set
 10 point– 9¾ Set

11/12 point– 10½ Set 10¾
 12 point– 12 Set
 13/14 point– 13 Set
 14 point– See different layout

NOTE: *Two lower case “e” in mat case. Choose either straight or slant bar.
 Mark in cut backs.